

## ASSEMBLY & INSTALLATION INSTRUCTIONS



Fixture  
BPD33448

### PREPARATION

1. Shut off the power at the circuit breaker and remove existing fixture, including the crossbar.
2. Carefully unpack your new fixture and lay out all the parts in a clear area. Be careful not to lose any small parts necessary for installation.
3. Use gloves when handling trim, crystals, and acrylic glass components during installation.  
Note: The fixture exceeds 50lbs and needs to be installed using an outlet box U.L. approved for 100lbs.

### MOUNTING CEILING PLATE (Fig. 1, Fig. 4)

3. Remove the canopy screw (F) from the fixture, and remove the mounting backplate.
4. Set color temperature at this stage. The fixture can switch between four color temperatures (3000k, 3500k, 4000k, 5000k), which can be adjusted to your preference using the 4CCT switch (Fig. 4) mounted on the canopy.  
**Note:** the switch comes with a detachable cover, remove the cover prior to adjusting the color temperature, reattach the cover after adjustment is made.
5. Secure the mounting backplate to the junction box using the original junction box screws.
  - (i) It is recommended to use only original junction box screws or replacements provided by junction box manufacturer.
  - (ii) The side of the ceiling plate marked "GND" must face out, towards the installer.

### ASSEMBLING AND WIRING FIXTURE (Fig. 1, Fig. 2, Fig. 3)

6. Choose number of down rods suitable for your application. Thread the fixture wires and safety cords through the rods, swivel and canopy.
7. Connect the canopy, rods, swivel and fixture body. Ensure all connections are tightened. **Note:** Due to limited space within the canopy, shorten the wiring as necessary to make the installation easier. Make sure to identify and label all the wiring properly (Fig. 3) before shortening wires.
8. Remove the short allen screw (E), pull out the extra safety cord through clamp, leave a loop for hooking, then secure the safety cords with clamp by tightening the short allen screw (E), hook the hooks into the safety cords. Hook the hooks on the mounting back plate slot.
9. All wires are connected as Fig. 2/Fig. 3 by using wire connectors (A) provided. Ensure all wire connectors are secure. Connect the fixture's ground wire to the ground in the junction box; this will be either a green wire or a bare copper wire. After driver is wired to house wires, tuck wires carefully inside the junction box.

### COMPLETING INSTALLATION AND INSTALLING CRYSTAL (Fig. 1)

















10. Lift and mount the canopy against the mounting backplate. Secure the canopy to the ceiling plate using the mounting screw (F).
11. Loosen the long allen screw (G), according to the label inside the lamp body and on the bag by number (1 to 1, 2 to 2, etc.); secure the crystal onto the fixture again by fastening long allen screw (G) with Allen wrench (D). Repeat these steps to install all crystals. Adjustment of screw on both sides of glass may be required for proper fit.

### NOTE: DIMMING WIRING INFORMATION (Fig. 3)

14. This fixture features electronic low voltage (ELV or TRAIC) or 0-10V dimming capabilities. See notes below for specific dimming wires information.
15. To utilize ELV or TRAIC dimming: use wires black (hot), white (neutral) and bare copper ground wire (ground).
16. To utilize 0-10V dimming: use wire purple (dim+), Pink or gray (dim-), black (hot), white (neutral) and bare copper ground wire (ground).

NOTE: Make sure to connect 0-10V prior to power-up the fixture in order to allow the 0-10V dimming to function properly.

### HARDWARE


							
							
Wire connector Qty: 7pcs+1Extra	Plastic Anchor Qty: 2pcs+1Extra	Wood Screw Qty: 2pcs+1Extra	Allen Wrench Qty: 1 pcs	Short Allen Screw Qty: 4pcs+1Extra	Mounting Screw Qty: 1Extra	Long Allen Screw Qty: 2Extra	Adjustable Clip Qty: 2pcs



Schonbek, 61 Industrial Blvd, Plattsburgh, New York, 12901  
Phone: 1-800-836-1892 | Fax: 518-563-4228 |  
www.schonbek.com

# ASSEMBLY & INSTALLATION INSTRUCTIONS

Fixture  
BPD33448



**WARNING**  
IMPORTANT: NEVER attempt any work without shutting off the electricity.  
o Read all instructions before installing.  
o System is intended for installation in accordance with the National Electrical Code (NEC), other applicable installation code(s) and local regulations by a licensed electrician familiar with the operation of the product and the hazards involved.  
o Go to the main fuse box, or circuit breaker panel. Place the main power switch in the "OFF" position and unscrew the fuse (s) or switch "OFF" the circuit breaker switch (es) that control the power to the fixture (s) or room that you are working on.  
o Place the wall switch in the "OFF" position.

o FAILURE TO INSTALL THIS FIXTURE IN ACCORDANCE WITH THESE INSTRUCTIONS MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND/OR PROPERTY DAMAGE.

**CAUTION**  
o All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to follow this instruction could invalidate the ETL/CETL Listing of this fixture.  
o When handling the fixture, do not apply pressure to the LEDs or bulbs. Hold the fixture by the base only.  
o Do not exceed maximum wattage noted on the fixture. Use only the recommended LED or standard lamps with the fixture.

**ADVERTENCIA**  
IMPORTANT: NUNCA trate de hacer ningún trabajo sin desconectar la electricidad.  
o Lea todas las instrucciones antes de instalar.  
o El sistema tiene por objeto la instalación de acuerdo con el Código Eléctrico Nacional, y otros códigos de instalación y reglamentos locales aplicables, por parte de un electricista autorizado que esté familiarizado con el funcionamiento del producto y los peligros involucrados.  
o Vaya a la caja de fusibles o al panel de disyuntores principal. Ponga el interruptor principal de alimentación en la posición de "APAGADO", y desenrosque los fusibles o "DESCONECTE" los disyuntores que controlen la alimentación a los dispositivos o la habitación en los que usted está trabajando.  
o Ponga el interruptor de pared en la posición de "APAGADO".  
o EL HECHO DE NO INSTALAR ESTE DISPOSITIVO DE ACUERDO CON ESTAS INSTRUCCIONES PODRÍA RESULTAR EN UNA LESIÓN PERSONAL GRAVE O LA MUERTE, Y/O DAÑOS A LA PROPIEDAD.

**PRECAUCIÓN**  
o Todas las piezas deben usarse como se indica en estas instrucciones. No sustituya ninguna pieza, no deje piezas fuera, ni utilice ninguna pieza que esté desgastada ni rota. El hecho de no seguir estas instrucciones podría invalidar la certificación ETL/CETL de este dispositivo.  
o Al manipular el dispositivo, no aplique presión a los LED ni las bombillas. Sujete el dispositivo solo por la base.  
o No exceda la potencia máxima indicada en el dispositivo. Use solo los LED o las bombillas estándar recomendados con el dispositivo.

**ADVERTENCIA**  
IMPORTANT: NUNCA trate de hacer ningún trabajo sin desconectar la electricidad.  
IMPORTANT: Ne JAMAIS entreprendre des travaux sans couper l'électricité.  
o Lire toutes les instructions avant l'installation.  
o Ce système est conçu pour être installé conformément au Code national de l'électricité ou d'autres codes d'installation et réglementations locales en vigueur par un électricien agréé connaissant le fonctionnement de ce produit et les dangers qu'il comporte.  
o Aller à la boîte à fusibles ou panneau principal de disjoncteurs. Placer l'interrupteur d'alimentation principal sur « ARRÊT » et dévisser le ou les fusibles ou mettre sur « ARRÊT » le ou les disjoncteurs qui contrôlent l'alimentation du ou des appareils électriques ou de la pièce dans laquelle vous travaillez.  
o Mettre l'interrupteur mural sur « ARRÊT ».  
o NÉGLIGER D'INSTALLER CET APPAREIL CONFORMÉMENT À CES INSTRUCTIONS RISQUE D'ENTRAÎNER DE GRAVES BLESSURES PERSONNELLES OU LA MORT AINSI QUE DES DOMMAGES MATÉRIELS.  
o MISE EN GARDE  
o Toutes les pièces doivent être utilisées comme indiqué dans ces instructions. Ne remplacer aucune pièce, ne laisser aucune pièce de côté ou n'utiliser aucune pièce usée ou cassée. Le non-respect de cette directive peut invalider l'homologation ETL/CETL de cet appareil.  
o Lors de la manipulation de cet appareil, n'appliquer aucune pression sur les DEL ou les ampoules. Maintenir l'appareil par la base uniquement.  
o Ne pas dépasser le nombre de watts maximum indiqué sur l'appareil. N'utiliser que les DEL ou ampoules standard recommandées dans cet appareil.

# ASSEMBLY & INSTALLATION INSTRUCTIONS

Fixture  
BPD33448



Fig. 1





Fig.4



Mounting BackPlate Dimensions




Fig. 2 Wiring




Fig. 3

